

09.00 uur



12.00 uur



15.00 uur



18.00 uur

21 maart





09.00 uur



12.00 uur



15.00 uur



18.00 uur

21 juni (zomertijd)






09.00 uur



12.00 uur



15.00 uur




18.00 uur

21 september (zomertijd)





09.00 uur



12.00 uur



15.00 uur



18.00 uur

21 december